

Parameter settings procedure

It is important that the following instructions are carried out carefully to reset the date, indicator and hour meter.

Reset Date –

1. Access the menu by pressing the UP and DOWN arrow keys (number 7 and 8) simultaneously, hold these in then press the ESCAPE key (number 4).
2. Tab down until the asterisk is at the side of CONFIGURATION.
3. Enter. (number 6)
4. Enter
5. Enter.
6. Using the arrow keys set the Day.
7. Enter.
8. Using the arrow keys set the Month.
9. Enter.
10. Using the arrow keys set the Year.
11. Enter.
12. Repeat numbers 4 to 11.

The Date is now set.

Reset the hour meter.

1. Using arrow key tab down until asterisk is at the side of RESET HOUR METER.
2. Enter.
3. Using arrow keys set the following digits.
4. '0'
5. Enter
6. '8'
7. Enter.
8. '4'
9. Enter.
10. '9'
11. Enter.

The hour meter is now set.

Reset the indicator

1. Using arrow key tab down until the asterisk is at the side of RESET INDICATOR.
2. Enter.
3. Using arrow keys set the following digits.
4. '0'
5. Enter.
6. '8'
7. Enter.
8. '4'
9. Enter.
10. '9'
11. Enter.

The indicator is now set.

The main display should now show 365 days.

Press the Enter key once, this will show the following information –

1. Today's Date on the top line.
2. Hours run 0.0 on the second line.
3. Machine 01 on the third line.
4. Vacuum setting on the bottom line 000/???

Press the Enter key once to return to the main screen.

At this point, you need to reset the machine to check all information has been stored in the memory. You can do this by turning the machine off then back on, or by pressing the reset button situated on top of the board.

Your machine should now run.